

Paper guide width setup (slider)


Slider adjustment:

- Feed the ticket stock into the printer against the fixed side of the paper path.
- Move the slider (*) over the stock until the inside touches the tickets.
- Back the slider a little away from the stock (approx. 1/32" or 1mm).


Caution:

Do not adjust the slider tight against ticket stock. This will cause feeding problem. Do not adjust the slider too far from the ticket edge either, this may cause tickets to move from side to side, which may also result in feeding problems.

RADJW & RADJ4 printers also need a print head setup, please see the "Print head setup for RADJ printers" manual.



Sample of a RADJW / RADJ4 paper guide



Sample of a ADJ2 paper guide



Sample of a ADJW / ADJ4 paper guide



Sample of a ADJW paper guide Lemur-C